

kaiser baas™



WiFi TV Plug User Guide



# CONTENTS

Safety precautions	2
What's in the box	3
Product diagram	4
Setting up the WiFi TV Plug	5
iPod touch, iPhone & iPad	6
Android	7
Apple Mac	8
Windows	9
Frequently Asked Questions	10
Product specifications	12
Contact us	12

# SAFETY PRECAUTIONS


Before using the WiFi TV Plug, please ensure you read and understand all the safety precautions below.

Do not attempt to open the case of the WiFi TV Plug or modify it in any way, as this will void your warranty. Maintenance and repairs should only be performed by Kaiser Baas.


- Keep the WiFi TV Plug away from water and other liquids. Do not use wet hands, as this may cause the unit to malfunction.
- Keep the product away from direct heat and sunlight.
- WiFi TV Plug may become slightly warm during use, this does not indicate malfunction.
- Do not place heavy objects on the WiFi TV Plug as this may cause the unit to malfunction.
- Do not dispose of the unit via conventional domestic waste.

# WHAT'S IN THE BOX

- A WiFi TV Plug
- B Rod antenna
- C User guide
- D Warranty card




# PRODUCT DIAGRAM



- 1 Power switch
- 2 Antenna connector (RF)
- 3 Reset button
- 4 Power plug
- 5 Status indicator
- 6 WiFi indicator

## SETTING UP THE WiFi TV PLUG


1. Attach the power plug adaptor to the WiFi TV Plug by first inserting the adaptor plug and then twisting the adaptor plug clockwise until you hear a click.



2. Connect a coaxial (RF) cable from the top of the WiFi TV Plug to your external antenna/TV point.
3. Plug the WiFi TV Plug into the wall power outlet.
4. Turn on the WiFi TV Plug by pressing the power button. Wait until the WiFi indicator flashes green.

# iPOD TOUCH, iPHONE & IPAD

1. Search for and download the "Tivizen DVB-T WiFi" from the App Store on your Apple device (iPod touch/iPhone/iPad).
2. Turn WiFi on.
3. \*Go to Settings > WiFi > Choose a network > iPlug.
4. Launch the Tivizen DVB-T WiFi App.
5. Select Country > Scan. Available channels will now display in a list.
6. To watch a program select a channel from the list.
7. To record a program, tap on the record  icon. A time counter will be displayed on screen when recording.
8. To view a recorded program, tap on any of your recorded programs.




Tivizen DVB-T App on Apple Store

\* This process may vary depending on which iOS you are using.  
Internet connection is required to download the App.

# ANDROID

1. Search for and download the "Tivizen DVB-T WiFi" App from Google Play on your Android device (tablet or phone).
2. Turn WiFi on.
3. \*Go to Settings > Wireless and Network > WiFi Settings > iPlug
4. Launch the Tivizen DVB-T WiFi App.
5. Select Country > Scan. Available channels will now display in a list.
6. To watch a program select a channel from the list.
7. To record a program, tap on the record  icon. A time counter will be displayed on screen when recording.
8. To view a recorded program, tap on any of your recorded programs.




Tivizen DVB-T App on Google Play

\* This process may vary depending on which Android device you are using.  
Internet connection is required to download the App.

# APPLE MAC LAPTOP/DESKTOP

1. Search for and download the "Tivizen DVB-T WiFi" from the App Store on your Apple Mac computer.




\* This process may vary depending on which OS you are using. Internet connection is required to download the App.

2. Turn WiFi on.
3. \*Go to Settings > Network > Network Name > iPlug
4. Launch the Tivizen DVB-T WiFi App.
5. Select Country > Scan. Available channels will now display in a list.
6. To watch a program select a channel from the list.
7. To record a program, click on the record  icon. A time counter will be displayed on screen when recording.
8. To view a recorded program, click on any of your recorded programs.

# WINDOWS LAPTOP/DESKTOP

1. Go to: <http://www.kaiserbaas.com/tv-radio-category/wifi-tv-plug>  
Click product “**support**” tab. The click “**Download software for Windows**”. Install and follow the prompts.



\* This process may vary depending on which version of windows you are using.

Internet connection is required to download the App.

2. Turn WiFi on.
3. \*Go to Control Panel > Network and Internet > Connect to a Network > iPlug
4. Launch the Tivizen DVB-T WiFi App.
5. Select Country > Scan. Available channels will now display in a list.
6. To watch a program select a channel from the list.
7. To record a program, click on the record  icon. A time counter will be displayed on screen when recording.
8. To view a recorded program, click on any of your recorded programs.

## FREQUENTLY ASKED QUESTIONS

**Q. The status indicator is flashing green.**

**A.** This indicates TV WiFi Plug is booting.

**Q. The Status Indicator is red.**

**A.** This indicates the unit is transferring data.

**Q. How do I disconnect the plug adaptor from the main unit?**

**A.** Press the release button on the back of the WiFi TV Plug . Then turn the plug adaptor counter clockwise and separate from the WiFi TV plug.

**Q. Can I connect multiple devices to the WiFi TV Plug?**

**A.** You can use the WiFi TV Plug on only one device at a time.

**Q. Can I browse the internet on my device whilst using the WiFi TV Plug?**

**A.** No, to browse the internet you must disconnect your device from the WiFi TV Plug WiFi connection and reconnect to your own WiFi settings.

**Q. I don't have a spare antenna point how can I use the WiFi TV Plug?**

**A.** Depending on how your TV is setup, you can plug the WiFi TV Plug into the RF output from your TV or set top box.

## FREQUENTLY ASKED QUESTIONS

**Q. When running the app, a message of “cannot find an accessory” is displayed.**

**A.** Ensure the device is on. Check the WiFi TV Plug connection is selected in your device’s WiFi settings.

**Q. How can I restore the unit to factory default?**

**A.** Check the TV WiFi Plug is turned on. Ensure the status indicator is solid green. Hold down the power button then push the reset button in with a paper clip. The status indicator will flash green rapidly. This will restore the unit to factory default.

**Q. The TV reception is poor. How can I improve this?**

**A.** Make sure the external antenna is connected and extended properly. Alternatively, reposition your device, to an area with stronger reception.

**Q. How can I record a TV program?**

**A.** You can record any TV program you are watching by pressing the record button.

**Q. Can I use more than one WiFi TV Plug in the same house?**

**A.** Yes, you can have as many as you like.

# PRODUCT SPECIFICATIONS

**Product Code:** KBA01019

**APN:** 9 326903 003605

## CONTACT US

Need further assistance? Please visit:

[www.kaiserbaas.com](http://www.kaiserbaas.com)

Or email:

[helpdesk@kaiserbaas.com](mailto:helpdesk@kaiserbaas.com)



kaiser baas™