

QUICK PAIRING YOUR DRONE

CONNECT



Turn on your Drone by holding the power button for 2 seconds.



The Drone lights will flash indicating it is ready to pair to your Remote Controller.

PAIRING



Turn on the Remote Control Transmitter.



Using the Left Throttle/Yaw Stick move it to the maximum UP position and return it back to the zero position.



The Drone LED lights will stop flashing indicating the Drone is now paired to the Remote Control Transmitter.



Press the Take-Off/Landing Button to arm the Drone. Press again for take-off.