

QUICK PAIRING YOUR DRONE

CONNECT



Turn on your Drone by holding the power button for 2 seconds.



The Drone lights will flash indicating it is ready to pair to your Remote Controller.

PAIRING



Turn on the Remote Controller.
The red light on the controller will flash.



Using the Left Throttle/Yaw Stick move it to the maximum UP position and then to down position.



You will hear two beeps from the Remote Controller and the Drone LED lights will stop flashing.



Press the Take-Off/Landing Button to arm the Drone. Press again for take-off.